Troubleshooting

If the TV does not react to the Remote Control or the front buttons, please switch OFF at the main switch for a few seconds and back On, then try again.

PROBLEM	CHECK ITEM	PAGE
No picture or sound	- TV not plugged in Outlet Power OFF	
	- Main Power button of TV not ON	6
	- Aerial not connected to terminal at the back of the TV set	5
	- Increase the volume.	15
Sound OK, poor picture	- Aerial not connected to terminal at the back of the TV set	5
	- Adjust CONTRAST, COLOUR and BRIGHTNESS controls	16
Picture OK, poor sound	- Increase the volume	15
Picture weak/No colour	- Aerial not connected to terminal at the back of the TV set	5
	- Adjust COLOUR control	16
	- Try fine tuning to correct	10
Poor reception on same channels	- Aerial not connected to terminal at the back of the TV set	5
	- Check for local interference	
 Remote control does not work	- TV not plugged in Outlet power OFF	
	- Main Power button of TV not ON	6
	- Turn OFF using the Main Power button, then turn On again after a minute	6
	- Check batteries in the Remote control	4

Part names


Infrared Transmitter Window
Aim this window at the infrared sensor on your TV set
CALL (🔔)/CHILD LOCK (🔒) button 23 / 19 – 21
SOUND MUTE (🔇) button 22
POWER/STANDBY (⏻/|) button 15
Programme Select buttons 15
FLASHBACK (↺) button 22
Returns to previously viewed programme
VOLUME UP (^)/DOWN (v) button 15
(^) Increases sound
(v) Decreases sound
(These are also used for menu setup)
CLOCK (🕒) button (Teletext) 25
REVEAL (👁) button (Teletext) 25
HALF PAGE (⊟) button (Teletext) 25
CANCEL (⊠) button (Teletext) 25
RESET (↻) button (Teletext) 25
23 TV/VIDEO Select button
15 Single/Double Entry button (1/2)
7 CHANNEL (PROGRAMME) UP (^)/DOWN (v) button
(^) Selects next higher programme
(v) Selects next lower programme
(These are also used for menu setup)
24 Text/Mix/Picture (⊟/◪/▢) Select button (Teletext)
24 – 25 COLOURED buttons
25 INDEX (⊡) button (Teletext)
25 HOLD (⏸) button (Teletext)
25 – 25 LIST Select button (Teletext)
25 – 25 STORE (⊞) button (Teletext)

SHARP ELECTRONICA ESPAÑA, S.A.

SHARP ELECTRONICS (U.K.) LTD.
Sharp House, Thorp Road, Newton Health,
Manchester M40 5BE

ECF PRINTED ON ENVIRONMENTALLY FRIENDLY PAPER

PRINTED IN SPAIN
TINS-7243BMN0
09/02

Quick Start Guide

SHARP

Quick Start Guide

15JF-26H



Installation



Insert two (AA or UM-3, 1.5 V) batteries into the remote control.
Position the positive and negative ends of the batteries as indicated.

If problems persist contact the SHARP Help line (office hours) on tel:08705-274277 [or (01)676 06 48 if telephoning from Ireland] and/ or WEB-SITE: **www.sharp.co.uk/support**

Quick Start Guide

Installation

4 Connect the Aerial Lead to the TV set.



5 Plug in your TV into the mains supply.



Typical connections

Typical connection (VCR and TV) through the RF terminal.



Turn your TV on

1 Press the main POWER(O|) button on the TV. The POWER indicator lights up in red.



2 The AUTO TUNING message will appear on your TV screen. Follow the instructions on the TV screen.



3

The AUTO TUNING function will tune all available TV stations into your TV. If you do not intend to use your TV with a VCR then please proceed to step 4.

If the TV is being used with a VCR, turn on the VCR and play back a prerecorded tape. If you have a SCART Lead, do not fit at this time.



Auto Tuning

4 Press the MENU button on the TV or remote control to start the AUTO TUNING. The tuning process may take several minutes.



5

After searching has finished the channels will be sorted in the following order (for example).

Prog.	Channel
1	CH21
2	CH31
3	CH41
4	CH51



If you wish to change the order, refer to the relevant section on page 13 of the operation manual.
If you need to repeat "AUTO TUNING", refer to the relevant section on page 7 of the operation manual.